

Installation Instructions for Fortress Fe²⁶ Welded Gate

It is the responsibility of the installer to meet all code and safety requirements, and to obtain all required building permits. The deck and railing installer should determine and implement appropriate installation techniques for each installation situation. The Fortress Company or its distributors shall not be held liable for improper or unsafe installations.

Fortress Fe²⁶ Posts must always be secured to the deck framing. Fortress Fe²⁶ Posts should never be attached to only the deck boards.


Read Instructions Completely Before Starting Installation

Required Materials

Eye Protection, Fortress Gate Kit #2 or other Hinge and Latch, Drill, Driver Bit, Tape Measure, and Pencil

Fortress Fe²⁶ Welded Gate

- Gate opening between posts is 36" if using Fortress Gate Kit #2
- If using Fortress Gate Kit #2, allow 3/4" space between gate frame and posts on each side for hinges and latch.
- Install supplied 1-1/2" Pressed Dome Caps on installed gate.



Fortress Gate Kit #2 (Item 650084)

